

# First start

[Main Page](#) > [TeltoCharge](#) > [Getting Started](#) > **First start**

## First start guide

Follow these steps to get started with TeltoCharge in a correct way:

Step Number	Description	Suggestions	Links
1	<b>Connect wires</b>	Different wire connections can be found in installation manual.	<a href="#">Electrical wiring diagrams</a>

2

**Pair**

Pairing code is the **last six digits of your installer code** which can be found on sticker. *Note: you have to pair to your device in first 5 minutes after turning power on. After 5 minutes, to pair - you will need to reboot the charger.*

[Full process is here](#)

3

**Finish set-up**

Choose: currency for electricity price, authorization, add NFC tags if necessary.

4

**Update device to the latest FW**

After pairing, choose your device in menu and baloon might suggest you to update firmware version, please be patient.

[How to update](#)

5

**Go to installer menu**

Go to settings, choose installer menu. To access it, please use your **full 9 digits installer code**.

[Full process is here](#)

6

**Configure your TeltoCharge**

To achieve maximum charger power, choose all electrical and functional configurations and press **Save** in the end. You can use suggested configurations below:

[Functionality descriptions](#)

Additional

Suggested configurations

Here you can see suggested configurations by your product power to achieve maximum TeltoCharge power.

[7.4 kW](#)  
[11 kW](#)  
[22 kW](#)