

https://wiki.teltonika-energy.com/view/Use_prefered_phase

Use prefered phase

there is an ability to use preferred phase while dynamic load balancing is on and charging is done on the single phase, otherwise the least loaded phase will be used.