

https://wiki.teltonika-energy.com/view/Allow_simplified_charging_sequence

Allow simplified charging sequence

Allow simplified charging sequence

There are electrical vehicles which do not use B state to start charging process and charging states goes directly from A to C. For that it requires simplified charging sequence enabled. If this option is turned OFF, TeltoCharge will not start charging with this type of EV connected.

By default this setting is turned OFF