


# NFC FAQ

No.	Question	Answer
1.	Why do I need NFC card?	NFC card is used to authorise user and unlock charger. If authorization is turned off user do not need to use NFC card.
2.	How to add/remove NFC cards/tags?	NFC cards/tags can be added via application. Go to settings > Add new card. After naming a new card/tag user have to touch NFC card/tag to the side of the charger. 
3.	Are the NFC cards/tags included in the package?	We provide 1 NFC tag and 1 NFC card with the charger, also there will be possibility to buy cards separately.
4.	Can I use my own NFC card?	Yes, but NFC card's has got requirements: <ul style="list-style-type: none"><li>• ISO 14443 A</li><li>• UID max size 10 bytes</li><li>• 13.56MHz</li></ul>
5.	How many NFC cards can be paired with TeltoCharge?	TeltoCharge can store ~100 NFC cards inside its memory. If charger is connected to any cloud management server, number depends on the server.